







PREPARE THE GROUND, UNWRAP THE PACKAGE,  
LAY OUT THE COMPONENTS, FIND THE TOOLS.

# BIANCA 28



4x40 × 65

4x50 × 500



5x70 × 10

6x140 × 45



M8x60 × 12

1,4x40 × 30

LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



BIANCA 28





MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

ASSEMBLE THE FOUNDATION  
WITH SCREWS




BIANCA 28

6x140 × 20  
Ø 5 mm




LAY OUT THE **BOTTOM** LOGS,  
**ATTACH** TO THE FOUNDATION.

BIANCA 28





THE WALL **LOGS** WILL HANG OVER  
THE FOUNDATION **BEAMS** BY  
**APPROXIMATELY** 5MM. THIS OVERHANG  
IS DESIGNED AS A RAIN DRIP. **5%**

ATTACH THE FIRST ROW OF  
**WALL LOGS** INTO THE BOTTOM  
LOGS WITH **SCREWS**.




BIANCA 28





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

BIANCA 28




SLIDE THE DOOR IN,  
ATTACH THE HANDLE.

BIANCA 28




DON`T FORGET TO  
**TIGHTEN** THE LOGS AFTER  
EVERY 3-4 ROWS.

BIANCA 28



SLIDE THE WINDOW IN,  
ATTACH THE HANDLE.

BIANCA 28



INSTALL THE GABLES WITH LONG SCREWS TO THE WALL LOGS ON THE FRONT AND REAR WALLS.

BIANCA 28

6x140 × 4  
Ø 5 mm

× 4

Ø 5 mm

× 4

A TL-1



A LG-3

GABLE

B TL-1

B LG-2




15 LOGS IN PLACE



INSTALL THE **ROOF** PURLINS AND **ATTACH** THEM WITH SCREWS.



BIANCA 28

6x140 × 6  
Ø 5 mm



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE END OF THE **PURLINS** AND ATTACH WITH 6 SCREWS, 3 INTO **EACH** NEXT, SAW THE LAST **BOARD** TO MAKE IT FIT.


4x50  
× 204



FOR THE FASCIA TRIMS INSERT  
SCREWS AFTER EVERY 0,5 METERS.

BIANCA 28

4x40  
× 32




EAVES EDGES GO ON TOP OF THE ROOFING\*.

\*(NOT INCLUDED)

4x40 × 32

Ø 3 mm





BIANCA 28

ATTACH ROMBS WITH SCREWS.


BIANCA 28

4x40  
× 4  
Ø 3 mm





20 SCREWS INTO THE FIRST FLOORBOARD,  
10 INTO EACH NEXT, SAW THE  
LAST BOARD TO MAKE IT FIT.

4x50  
× 270




BIANCA 28




FB

SAW THE **BASEBOARDS**  
AND ATTACH WITH NAILS  
AT **EVERY 0,5** METERS.

1,4×40  
× 30



BIANCA 28





BB

DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.


M8x60 × 12

Ø 8 mm

BIANCA 28






WINDBOARD




IF DOOR IS TILTED,  
PUSH THE DOOR FRAME SO  
THAT ALL CORNERS ARE  $90^\circ$ .

BIANCA 28



IF **DOORS** ARE IN DIFFERENT HEIGHTS  
OR THERE IS A GAP **BETWEEN** THEM,  
**ADJUST** 3 SCREWS ON DOOR HINGES.

BIANCA 28



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

BIANCA 28

