







PREPARE THE GROUND, UNWRAP THE PACKAGE,  
LAY OUT THE COMPONENTS, FIND THE TOOLS.



# CARINA 28



LAY OUT THE FOUNDATION BEAMS AND SQUARE IT BY MEASURING FROM CORNER TO CORNER.



CARINA 28




MAKE SURE THAT THE FOUNDATION IS INSTALLED ON A LEVEL SURFACE. CHECKING ALL DIRECTIONS, INCLUDING CORNER TO CORNER. 3%

LAY OUT THE FOUNDATION BEAMS  
AND SQUARE IT BY MEASURING  
FROM CORNER TO CORNER.




CARINA 28

6x140  
× 20



LAY OUT THE **BOTTOM** LOGS,  
**ATTACH** TO THE FOUNDATION.




CARINA 28



THE WALL **LOGS** WILL HANG OVER  
 THE FOUNDATION **BEAMS** BY  
**APPROXIMATELY** 5MM. THIS OVERHANG  
 IS DESIGNED AS A RAIN DRIP. **5%**


ATTACH THE FIRST ROW OF  
**WALL LOGS** INTO THE BOTTOM  
LOGS WITH **SCREWS**.

CARINA 28





AFTER PLACING 3-4 ROWS OF WALL LOGS, TAP EACH WALL LOG IN PLACE USING A HAMMER AND THE HITBLOCK PROVIDED, TO TIGHTEN THE LOGS.

CARINA 28




SLIDE THE DOOR IN,  
ATTACH THE HANDLE.

CARINA 28




DON`T FORGET TO  
**TIGHTEN** THE LOGS AFTER  
EVERY 3-4 ROWS.

CARINA 28



SLIDE THE WINDOW IN,  
ATTACH THE HANDLE.

CARINA 28




INSTALL THE **GABLES** WITH **LONG SCREWS**  
TO THE WALL LOGS ON THE FRONT AND  
**REAR** WALLS.

CARINA 28

6x140 × 8



Ø 5 mm




INSTALL THE **ROOF** PURLINS AND  
ROOF ELEMENTS 1, **ATTACH** THEM  
WITH SCREWS.

6x140  × 6

Ø 4 mm 




CARINA 28



PLACE THE FIRST **ROOFBOARD** FLUSH WITH THE **END** OF THE PURLINS AND ATTACH WITH 10 SCREWS, 5 **INTO** EACH NEXT.

CARINA 28


4x50  
× 185



EAVES EDGES GO ON TOP  
OF THE ROOFING\*.  
\*(NOT INCLUDED)

CARINA 28

4x40  
× 24





FOR THE FASCIA TRIMS  
INSERT **SCREWS** AFTER EVERY 0,5 METERS.

CARINA 28


4x40 × 28

Ø 3 mm




20 SCREWS INTO THE FIRST FLOORBOARD,  
10 INTO EACH NEXT, SAW THE  
LAST BOARD TO MAKE IT FIT.

4x50  
× 270





CARINA 28



FB

SAW THE **BASEBOARDS**  
AND ATTACH WITH NAILS  
AT **EVERY 0,5** METERS.

1,4X40  
× 30




BB


DRILL THROUGH THE WALL, HOLE MUST BE AT THE BOTTOM OF THE OVAL, ATTACH WITH BOLT.

M8x60 × 12

Ø 8 mm






CARINA 28



WINDBOARD


IF DOOR IS TILTED,  
PUSH THE DOOR FRAME SO  
THAT ALL CORNERS ARE 90°.

CARINA 28



IF **DOORS** ARE IN DIFFERENT HEIGHTS  
OR THERE IS A GAP **BETWEEN** THEM,  
**ADJUST** 3 SCREWS ON DOOR HINGES.

CARINA 28



WHEN THE **HOUSE** IS ASSEMBLED, YOU SHOULD **COVER** THE TIMBER WITH **WOOD** PROTECTIVE SEAL, PAINT OR **STAIN** AS SOON AS POSSIBLE TO AVOID DETERIORATION TO THE **WOOD**.

CARINA 28

